


Requirements:

Note: This is only a Main System Software update via USB drive

- USB stick with at least 2 GB memory.
- A Windows based PC or notebook to prepare the USB.
- **Make sure that the navigation microSD card is inside the microSD card slot of your ZENEC naviceiver (!) Don't take out navigation microSD card.**

Note: The USB stick must be formatted to FAT32 before use (right-click on the USB drive in the Win Explorer → choose "Format" → select FAT 32 → start).

Installation of Main System Software Update via USB drive:

1. Download the software update package "Z-E4626_NON_SW_v2.1.0.exe".
2. The software package is a self-unzipping executable. Start extraction with a double-click and select your USB stick as target for the uncompressed files.
3. **After the downloaded file has finished extracting, check that there is a folder on the USB called  C10_SW_Update before ejecting the USB from the computer.**
4. **Make sure that the navigation microSD card is inside the microSD card slot of your naviceiver (!) Don't take out navigation microSD card.**
5. Connect the USB stick to your naviceiver.
6. Enter the naviceiver setup. Tap on "Device Setup" → "Help" → "Software Update" → "OK".
7. The naviceiver will restart and show the **ZENEC boot logo for 55sec.**, then auto-switch to update dialog menu.
8. Make sure that checkbox "1. APP" is selected. If so, tap on the "Update" button to start the update process.
9. Your system will be updated in a step-by-step process. The complete update procedure takes approx. 2 minutes. A status bar shows the update progress.
10. Please restart your ZENEC naviceiver if the update process has completed successfully.
11. Calibrate the touch screen with a suitable pen.
12. Remove the USB stick.
13. **Enter the naviceiver setup. Tap on "Device Setup" → "Help" → "Load Factory" → "OK".**
14. Please do a version check.

Version checking:


After completion of the software update, version checking is crucial to validate full success. If the installed software version differs with listed versions below, a full re-installation of the entire software update is required.

Review of device software version:

To check the Main Software Version, enter the naviceiver setup. Tap on "Device Setup" → "Help" → "Version Info".

Version: 2.1.0
DeviceID: Z_E4626_NON

Notes:

- Do not operate or turn off while device is performing a software update.
- After completion of the software update always load the factory defaults. [Setup → "Device Setup" → "Help" → "Load Factory" → "OK"]
- If you use a USB to play music, you will need to remove a previous history folder. Please delete:  ZENEC_Playlists

Improvements + Bugfixes:

MainSystem General

- Improved system stability and performance

Tuner

- Improved response of DAB menu items during scan. Skip buttons and external SWC short press functions remain working. Long press keeps changing through Ensembles.

Setup

- Bugfix for 180° mode in the x-over menu. 180° setting remains set after ACC OFF/ON.
- Audio bugfix for "reduced volume setting" when entering reverse gear, Mute state will not unmute upon release of reverse gear.